

- **Step 1**Verify that no devices are connected to the switch. Initially, the switch acts as a DHCP server.
- Confirm that the STAT LED is solid green. This indicates that POST is complete. If the STAT LED turns amber, the device failed POST. Reconnect the AC power cord to the AC power connector of your device and to a grounded AC outlet.
- Step 3 Press and hold the **Reset** button for 3 to 4 seconds and release it.

 Caution: Release the **Reset** button after 3 to 4 seconds. Continuing to hold the **Reset** button for longer exits the Setup mode.
- Step 4 Connect an Ethernet cable to a port on the switch front panel and to a free Ethernet port on the server.
- Step 5

 Verify that the port LEDs on the server and on switch are solid green or blinking green. This indicates a successful connection.